

PHX 551 + 552 Stlye Reddot

Achtung: Drehen Sie die Seitenverstellung des Reddots nicht mit aller Gewalt auf Anschlag!
Andernfalls können die Kabel im Inneren Schaden nehmen.

Wird dies nicht beachtet und eines der Kabel löst sich vom hinteren Kontakt, so muss dieses wieder angelötet werden.

Ausreichend Kabellänge steht zur Verfügung. Bevor Sie das Kabel erneut anlöten, stellen Sie sicher, dass die Seiteneinstellung vollständig auf der nicht zu lötenden Seite steht. Somit ist ausreichend Platz, auch für größere LötKolben.

Caution: Do not forcefully turn the red dot's adjustment dial all the way to the stop!
Doing so may damage the internal wiring.

If this is not observed and one of the wires becomes detached from the rear contact, it must be soldered back on. Sufficient cable length is available. Before resoldering the wire, make sure that the side adjustment is fully turned to the opposite side of the one being soldered. This ensures there is enough space, even for larger soldering irons.



