Instruction Manual

SAR K98

Contact:

Email:info@begadi.com

Add:Dietinger Straße 23 78661 Dietingen - Böhringen Deutschland

SAR K98 Instruction Manual

CONTENTS

Introduction

Kar 98k Mauser was derived from Gew 98 Mauser,
Kar 98k was the standard rifle of the Nazi Germany military equipment in the World War Ⅱ。It was in service from 1935,and was standard rifle of Nazi German until
the end of World War Ⅱ.Kar 98k was one of the most productive light weapons during World War Ⅱ.
Our company is constantly researching new ways to innovate in designs and materials to ensure the best quality of our products.We select beech wood imported from Germany ,and the products' hardware accessories are designed and built with computer assisted design tools such as Computer Numerical Control（CNC）turning operation to ensure tight precision and quality.
Our company values our customer's feedback，as we incorporate improvements and upgrades to our future products.

Contents

01 ..... INTRODUCTION
02 ..... COMPONENTS
03 ..... WARNING
04 ..... SELECTOR AND SAFETY SETTING
05 ..... INSTALLING CO2 CARTRIDGE
06 ..... SIGHT ADJUSTMENT
07 ..... REMOVING THE BOLT
08 ..... LOADING THE MAGAZINE
09 ..... PARTS LIST
10 ..... MAINTENANCE
11 ..... TROUBLE SHOOTING

Introduction

TROUBLE SHOOTING

1、Check to ensure that your lubricant reservoir is at the required level for optimal operation. This can cause mechanical malfunctions if not properly maintained.
2、Point the muzzle in a safe direction and inspect the chamber or feed tube if the weapon doesn't fire. Typically, a pellet or BB may jam inside the chamber, causing the airsoft gun not to fire, or other debris may be inside the barrel or chamber. Place the airsoft gun on "Safe." Look inside
the chamber or feed tube to locate and remove the jam or debris. A slender pointed tool or tweezers can be used to grab jammed ammunition or other debris.
3、Check all O-rings, air seals and pistons if the weapon isn't shooting at its indicated velocity range. Low air pressure causes poor range performance. Consult your specific manual to access the O-rings, seals and pistons. Look for any visible damage or worn spots. Replace the items if needed.
4、Check the CO2 cartridge, if the gun is so equipped. Often, poor performance is caused by low CO2 levels. You may hear a loud burping sound, or the airsoft gun won't fire properly when the CO2 is low or empty. Ensure that the CO2 cartridge is properly installed and sealed correctly. Installing a fresh cartridge generally corrects this problem.
5、Adjust your sights or scope if the airsoft gun isn't firing on target accurately. If no other problems are evident, fine tuning the sights or scope will bring your shots back on target. Often, the sights can become out of tune through transport, improper storage or dropping the weapon. Consult your specific manual for detailed sight adjustment procedures.

When Hopping Up is improper

SYMPTOM	POTENTIAL	CORRECTIVE
Pellets flying upwards	Too much hop setting.	Gradually return adjustment lever backward.
Short flying distance of pellets (less hopping up effect)	Too much hop setting.	Gradually return adjustment lever forward.
	Hop packing contaminated by oil or dirt.	Fire pellets equivalent to 4 to 5 magazine or clean the chamber using cleaning rod.
	Dirt inside a barrel.	
	Worn or damaged hop packing.	Purchase the replacement part at your dealer or from PPS and replace it.
Cannot adjust	Damaged adjustment lever or other pasts.	Purchase the replacement part at your dealer or from PPS and replace it.
Frequent pellet clogging	Too much hop setting.	Gradually return adjustment lever towards Normal.
	Improper size BB pellets.	Use standard 5.59mm BB pellet.
	Dirty hop packing.	Clean using the cleaning rod or consult your dealer or PPS for repair.





For more product information please visit our website

■ **Components**

SAR K98

K98-01	Bolt handle set	K98-05	Trigger guard set
K98-02	Rear sight	K98-06	Hop-up set
K98-03	Bolt/Rear sight set	K98-07	Front sight set
K98-04	Receiver set	K98-08	Magazine Set



• You may buy all of the groups'parts from PPS support Dep or your Local PPS distributor.

Operation of this air gun for competition use is restricted to users of 18 years old or more,careless shooting and wrong operation are dangerous,causing eye damage or other injury.

警告 WARNING



You may be liable for damaging public or personal property or for injuring a person or an animal even if you only meant to shoot as a "practical joke."Always observe good manners and enjoy fun sport shooting.



Select a safe place for operating the air gun,avoid places where people and cars are around.

Looking into the muzzle is extremely dangerous regardless of BBs having been loaded or not.If you get hit in the eye by a BB pellet,you may in worst case,loose your eye sight.

Activating the trigger carelessly is extremely dangerous.Never put your finger on the trigger unless the safety cap is removed and you are ready to shoot a target.



Safety procedures:
1.Attach the safety cap to the muzzle.
2.Set the selector lever to the safety position.
3.Remove the magazine.
4.Remove the battery.

When you carry the air gun,attach the safety cap,set the selector lever to the safety position and always put the air gun in a case or bag.



There may be cases where some BB's remain in the gun after the magazine has been removed
After removal of the magazine,direct the muzzle towards a safe direction and pull the trigger to confirm that there are no BB's remain in the gun,then attach the safety cap.

Disassembling or modifying the gun may adversely affect the performance and make it dangerous."It may be against the Law."

When shooting the air guns for target practice or in a game situation,you and all participants must wear safety goggles or other eye protective gear.Also,pay attention to ricochets.It is very important to pay attention to third parties other than the participants.



Always attach the safety cap to the muzzle,remove the battery and store the air gun in a case or bag and at a place that is out of reach by children.



Never direct the muzzle towards a person,animal or in any direction.That may cause harm or damage to the third party.

Make sure to put the barrel and safety cap on the muzzle,except when you are shooting.Do this to prevent accident,discharge of BB's and also for dust protection purpose.Never pull the trigger while the barrel and the safety cap is attached.

Adult supervision required.Always wear safety goggles when shooting.Misuse or careless use may case injury,May be dangerous up to 50 meters.Read all instructions before using the airsoft gun.The purchaser and user should conform to all laws governing use and ownership of airsoft guns.

1

▸ Adjust the initial velocity

2



Rear sight adjustment

▸ Press the button and slide forward or backward for adjustment.

3

▸ Remove the front sight hood.

4



▸ Turning the screw will move the pellet hitting point to the left or right.

5

▸ Load 11rds 5.95mm BB pellets into the magazine

■ Selector and safety setting

SAR K98